Wall

Wall line count 3

Minimum Wall Line Width Default 0.34 - Change to 0.015

Print Thin Walls Check the box

**Top Bottom** 

Top Layers 5

**Material** 

Printing Temp Initial Layer 205
Building Plate Temp Initial 65

**Speed** 

Initial Layer Speed 15 Skirt/Brim 25

**Travel** 

Retractions Check the box

Retraction Distance 4 or 3
Retraction Speed 40

**Build Plate Adhesion** 

Build Plate Adhesion Skirt Skirt Line Count 3

**Special Modes** 

Specialize Outer Contour Check the box Smooth Spiralized Check the box

**Preferences** 

Configure Cura
Printer
Machine Settings
G28G29