Wall

Wall line count 3

Minimum Wall Line Width 0.34 - Change to 0.015 or 0.15

Print Thin Walls Check the box

Top Bottom

Top Layers 5

Material

Printing Temp Initial Layer 205
Building Plate Temp Initial 65

Speed

Initial Layer Speed 15 Skirt/Brim 25

Travel

Retractions Check the box

Retraction Distance 4 or 3
Retraction Speed 40

Build Plate Adhesion

Build Plate Adhesion Skirt Skirt Line Count 3

Special Modes

Specialize Outer Contour Check the box Smooth Spiralized Check the box

Preferences

Configure Cura
Printer
Machine Settings
G28G29